

Vlies (fleece) Dreambox® 3.0 filter unit and ECO Dreambox® Vlies (fleece) / Single ECO manual for automatic version, step by step

The Vlies (fleece) Dreambox® and the ECO Dreambox® filter are similar in function.

The timer used is for setting the time of rolling after the float has given a signal. **IMPORTANT:** Please make sure, that the sensor is attached to the wall of the filter and is not wet, it's a very low-maintenance device and is pre-installed for immediate use. Ideally, it should be fixed in the center of the filter, by means of the plastic screw.

The sensor determines the filling level of the filter with water (water level). When triggering, the LED lights up.



The Panasonic Timer is relatively easy to use. **T1** = waiting time before rolling up **T2** = roll-up time

With the Set/Lock button (bottom left) you can switch between T1 and T2.

The time is set with the blue UP/DOWN buttons.

