

## Vlies (fleece) Dreambox® 3.0 filter unit and ECO Dreambox® Vlies (fleece) / Single ECO manual for automatic version, step by step

The Vlies (fleece) Dreambox® and the ECO Dreambox® filter are similar in function.

The timer used is for setting the time of rolling up after the float has given a signal. **IMPORTANT:** Please make sure, that the sensor is attached to the wall of the filter and is not wet, it's a very low-maintenance device and is pre-installed for immediate use. Ideally, it should be fixed in the center of the filter, by means of the plastic screw.

**The sensor determines the filling level of the filter with water (water level).** When triggering, the LED lights up.



The Panasonic Timer is relatively easy to use. **T1** = waiting time before rolling up **T2** = roll-up time  
With the Set/Lock button (bottom left) you can switch between T1 and T2.  
The time is set with the blue UP/DOWN buttons.

